

Functions D&H

Elektrischer Triebwagen ET 89 'Rübezahl'



F Key	Funtion	Random	Slot
F0	Lights on if fitted		
F1	Sound on		1, 2
F2	Whistle playable		3
F3	Whistle Attention		9
F4	Shunting gear		
F5	Guard whistle (standing)		15
F6	Whistle Short		10
F7	Coupler sound & aux 6 (standing)		
F10	Brake key (active)		12
F11	Continuous pneumatic bell		11
F12	Sand valve		16
F13	Force acceleration (more tractive effort)		
F14	Air compressor	X	4
F15	Pantograph Up (idled without engine sound))		13
F16	Pantograph Down (idled without engine sound)		14
F17	Parking brake set (standing)		6
F18	Parking brake release (standing)		7
F19	Sound gradually quieter		
F20	Sound gradually louder		
F21	Brake sound		
F22	No braking sound		
F23	Sound fader out		
F24	Non aceleration / deceleration (no inertia)		